



STABLE DOOR KIT

- 1) With the door in the closed position, measure the width of the door from the outside, and cut the deflectors to this size.
- 2) Hold the deflectors up to the door and mark on the metal where it hits the door stops, trim to clear the door stops by 3mm on both ends. Cut the section DDS1 to the same size.
- 3) Position the deflector section 50mm from the bottom of the top door and screw into place.
- 4) Position the other deflector section 50mm from the bottom of the bottom door and screw into place.
- 5) Attach the supplied black edge covers to the deflectors, using glue for a permanent fix.
- 6) Fix DDS1 into position, checking that the door opens and closes before screwing in, ensuring that the top door closes against the seal.
- 7) Measure the inside width of the door, and cut DDS2 to this size, fix to door as shown below.
- 8) Fix the DDS end caps if required.

