



SG 44 FITTING INSTRUCTIONS

1. Ensure door height suitable to meet required 13 - 15mm.
2. Measure width between the door frames and cut the threshold to fit neatly. Push the threshold up to the door stops and screw down fully and use sealant on the underside and at the ends.
3. Press home seal into the other grooved ensuring contact all along its length.
4. (a) For heavier traffic embed the threshold in cement mortar.
(b) If the gap under the door is too large fit a strip of wood to the door bottom.
(c) Replacement seals are available.